

Instructions For:

Outdoor Step Stake - Flying Banner Base


Product Specifications

Flying Banner Displays Sold Separately.
Foot Print Dimensions: 8" W x 1" D

Product Parts

1 - Outdoor Step Stake

1



Step 1

** Before instructions for Flying Banner Display **

Position the Base in dirt or grass, place your foot on the cross bar, and firmly press into the ground.

Step 2

** In place of Step 2 on instructions for Flying Banner Display**

Place the Base Insert (7 of Flying Banner Display Parts) in the hole on the top of the Base.

