

Instructions For:

Cardboard Cutout Holder




Product Specifications

Recommended Graphic Size: 24" W x 62" H
Maximum Graphic Size: 48" W x 74" H
Foot Print Dimensions: 18" W x 15.5" D

Product Parts

- 1 - Graphic Backer
- 2 - Hook
- 3 - Vertical Support Rods
- 4 - Bottom Support Rod




Step 1

Take all parts out of the box.


Step 2

Lay the unit on a clean, flat surface.
Apply Double-Sided Tape (sold separately) to the flat side of the Graphic Backer (1).
Remove the protective film from the double-sided tape, and apply the Graphic to the tape.



Step 3

Lay the unit face down.
Insert the top ends of the Vertical Support Rods (3) into the holes on the sides of the Graphic Backer (1).



Step 4

Stand the assembled unit upright.
Place the loop end of the Bottom Support Rod (4) over the Hook (2) on the bottom of the Graphic Backer (1).
Place the unit in the desired location.

