

Instructions For: The 10' Splash




Product Specifications

Total Graphic Print Size: 88.6" H x 143.7"W
 Visible Graphic on Front: 88.6" H x 119" W
 Visible Graphic on Sides: 88.6" H x 12.35" W
 Foot Print Dimensions: 119" W x 12.35" D

Product Parts

- 1 - Splash Stand
- 1a - Locking Clips
- 1b - Hook & Loop; Hook
- 2 - Extra Hook & Loop
- 3 - Carrying Case




Step 1

Remove all parts from the bag. Place the unit on the ground/work surface

Step 2


Recommend set up with two people.

Pull the Splash Stand (1) out from corners until it is fully expanded on the floor. Be sure front side is up (side with Hook & Loop (1b) on all frame edges as shown below).




Step 3

Snap all Locking Clips (1a) together to secure the Splash Stand (1) in expanded position.




Step 4

Attach Splash Graphic by connecting the Loop on the Splash Graphic to the Hook (1b) on the Splash frame.



Step 5

Your graphic will attach all the way around to the sides as shown.



Taking Down the Splash

1 - Remove Splash Graphic from stand. **Do not collapse the Splash Stand with the Graphic attached as this may damage the Graphic.**

2 - Lay frame down and unlock all of the Locking Clips (1a) as shown.

3 - Gently collapse the Splash stand from corners and store in carrying Case (3).

