

Instructions For:

Lighted LED Signs - Open




Product Specifications

Dimensions: 23" W x 14" H x 1" D

Product Parts

- 1 - LED Sign
- 2 - Power Cord
- 3 - Chain & Rings



Step 1

Take all parts out of the box.

Step 2

Attach the chain clips (3) to the hooks on the top of the LED sign (1).



Step 4

Pull cord to turn LED sign (1) on and off.

- Click 1 - Off
- Click 2 - Solid
- Click 3 - Animated
- Click 4 - Off



Step 3

Plug the power cord (2) into the LED sign (1) and into the wall outlet. Hang sign where desired.

